



GUNNTRAC 5

Installation Instructions

GUNNTRAC 5

Important! GUNNTRAC 5 is manufactured extra long to fit a variety of tire dimensions. The user must therefore adjust the length of the tire protection to suit the actual tire size.

The adjustment of GUNNTRAC 5 is quite simple to perform but keep in mind the following:

- Do not shorten too much!
- Important that the GUNNTRAC 5 is loosely mounted on the wheel so that it can move easily over the tire pattern and absolutely NOT stuck in the tire bars when the wheel rotates.
- Follow the installation instructions carefully.

1

info@nordictraction.fi • +358 207 927 500



Stage 1.

Place GUNNTRAC 5 on the ground behind the tractor. The crooked side shall be upwards. Attach a rope loop to the T-connectors and place the loop between suitable tire ribs.

Stage 2.

Slowly drive the tractor and ensure that the chain falls down with even distribution on the deck sides.

Stage 3.

Stop the tractor when the end of the tire is approx. 0.5 meters above the ground.

Stage 4.

The chain must be very loosely mounted on the wheel, therefore the tire must be worn. Be extra long to not get stuck in the tire tracks while driving. Stretch the treadmill to the maximum, then slacken it approx. 150 mm = 8 links and hood nearest broddade link.



Stage 5.



Important to cut a lying brace link to fit the T-joints standing unbroken links.

Stage 6.



Slimattans ends are coupled with T-couplings.

Stage 7.



Stretch the side rails to the maximum, then slacken it approx. 270 mm = 8 links. Step the locking arm in the appropriate side chain link. The side chain surplus can be cut or wooded on the locking arm.